



UPB Standard Dimming Transceiver Switch with Timer Model US1-40

Provides ON/OFF, dimming and timed OFF control for:

- Incandescent lighting
- Magnetic low-voltage lighting
- Halogen lighting

IMPORTANT!
Read This Before Installing!

- This incandescent dimmer **cannot be used to dim FLUORESCENT, ELECTRONIC LOW-VOLTAGE or METAL HALIDE lighting, unless specifically allowed by the lighting manufacturer. Please see instructions to configure this product for ON/OFF operation with these types of lighting.**
- **DO NOT WIRE HOT!** Permanent damage may result. Improper installation voids the warranty.

Model US1-40 shown with
actuator faceplate (sold separately)



FUNCTION

The SimplyBrilliant™ UPB Dimming Transceiver Switch, model US1-40, provides direct load control and or remote control of permanently-installed new or existing lighting fixtures, lamps and other electrical devices connected to UPB devices. Incandescent lamps can be turned ON or OFF, and can also be dimmed and brightened. The timer function can be used to automatically turn OFF loads, after a preset time, like bathroom fans or heat lamps. The US1-40 can be configured to turn other types of non-dimmable loads ON and OFF. Single rocker faceplate model series ZS11 are sold separately and available in gloss colors: white, ivory, almond, brown or black. The switch may also act as a transmitter or receiver that can communicate with other UPB devices, either individually or collectively for lighting scenes.

IMPORTANT SAFETY INSTRUCTIONS

When using electrical products, basic safety precautions should always be followed, including the following:

1. READ AND FOLLOW ALL SAFETY INSTRUCTIONS.
2. Installation should be performed by a qualified electrician.
3. Keep away from water. If product comes into contact with water or other liquid, disconnect immediately.
4. Never use products that have been dropped or damaged.
5. Do not use this product outdoors.
6. Do not use this product for other than its intended use.
7. Do not connect multiple lamps that, when combined, exceed the maximum load rating of the product, de-rated for multi-gang boxes.
8. Do not install in areas that can exceed 120°F (e.g., in an attic).
9. To avoid the risk of overheating and possible damage to other equipment, do not use this product to control a receptacle.
10. Do not cover the product with any material when in use.
11. SAVE THESE INSTRUCTIONS.

CAUTION: DO NOT CONNECT TO RECEPTACLE, USE MODEL URD. The default switch configuration operates as a dimmer for incandescent lamps. It will also dim magnetic low-voltage and halogen lamps. To control fluorescent, electronic low-voltage or metal halide lamps, or motor-operated appliances, transformer-supplied appliances or fans, the switch **must be reconfigured** for ON/OFF operation (dimming disabled) prior to use. Refer to the section on Configuration.

ATTENTION: NE PAS SE CONNECTER A RECIPIENTS, UTILISEZ URD MODELE. La configuration de changement implicite opère comme un variateur pour les lampes incandescentes. Il baissera aussi le voltage bas magnétique et les lampes d'halogène. Contrôler le voltage bas fluorescent, électronique ou le métal halide les lampes, ou les appareils opérés de moteur, les appareils fournis de transformateur ou les fans, e changement doit être reconfiguré pour SUR/DE l'opération (baisant rendu infirme) avant l'utilisation. Faites allusion à la section sur la Configuration.



CAUTION: DO NOT WIRE THIS DEVICE WITH POWER CONNECTED. Injury or permanent damage to the device may result. Improper installation voids the product warranty.

INSTALLATION

The SimplyBrilliant™ UPB Dimming Transceiver Switch (US1-40) is designed to be installed in a junction box that is wired to a readily accessible over-current protection device in the building wiring per NEC and CEC electrical codes.

Locate the existing wall switch for the lighting to be controlled. Note that the lamp rating (or the combined rating of all connected lamps) must not exceed what is shown in the de-rating table below.

Table 1:
Power per Dimmer

	Number of Load Dimmers in J-box		
	1	2	3+
Number of J-box Gangs	1 600W	2 800W	3+ 900W
	--	500W	--
		700W	500W

2. Disconnect power at the circuit breaker.
3. Remove the existing wall switch hardware. Disconnect the wires to the switch.
4. Using a wire nut, connect all white (Neutral) wires together.
5. Using a wire nut, connect the brown (load output) wire of the US1-40 to the black wire of the load/fixture to be controlled.
6. IF THIS IS TO BE A 3- OR MORE-WAY INSTALLATION, use a wire nut to connect the brown/white "REMOTE 1" traveler wire to the "REMOTE 1" connection of the model USR 3-way switch. See wiring diagrams on page 2.
7. Using a wire nut, connect the black (Line) wire of the US1 switch to the black (Line) power wire.
8. Mount the switch inside the J-box using captive screws. DO NOT OVERTIGHTEN THE SCREWS.
9. Reconnect power at the circuit breaker.

CONFIGURATION

Configuration requires UPB setup/configuration software and a model UMC Computer Interface Module. Before using UPStart configuration software, be sure to download the latest version from the Simply Automated website. First time users should also download and follow the Quick Start Guide and use the Installation Wizard available in UPStart to save time.

The US1-40 default settings assume a ZS11 (single rocker) faceplate. **The device will not operate correctly with any other model of faceplate.**

SETUP MODE

When first adding a US1 to a UPB system network, it is necessary to place the US1 in SETUP mode in order to initiate self-identification on the powerline. To place the US1 in SETUP mode, tap rocker exactly 5 times quickly. The LED indicator will continuously blink GREEN when the unit is in SETUP mode. To exit SETUP mode and enter NORMAL mode, tap the rocker twice quickly.

OPERATION

Unless otherwise configured, rocker actuator behaves as follows:

Rocker Event	Dimmer Action	
	Top Rocker	Bottom Rocker
Single-Tap	Brighten to 100% at Default Rate	Fade to 0% at Default Rate
Double-Tap	Snap to 100%	Snap to 0%
Hold	Start brightening to 100% at Default Rate	Start fading to 0% at Default Rate
Release	Stop brightening and hold current level	Stop fading and hold current level

1. By linking a transmitting switch to a (non-dimming) UPB Receptacle, Appliance Module or Relay Module, the connected load can be turned ON by tapping the top of the rocker and OFF by tapping the bottom of the rocker.
2. By linking a transmitting switch to a (dimming) UPB Lamp or Fixture Dimmer Module, the connected load can be controlled according to the table above.

A timer function is available in the US1-40. Controller commands or rocker taps can turn ON the load and preset the timer period. The US1-40 automatically turns OFF at the end of the period. The available preset times are: 1 Sec., 5 Sec., 30 Sec., 1 Min., 2 Min., 4 Min., 10 Min., 20 Min., 30 Min., 40 Min., 50 Min., 1 Hr., 2 Hrs. 3 Hrs. and 4 Hrs. The default setting is: Timer Off.

To turn lights on faster, local response time adjustments are available (300, 450, 600 and the default 750 mSec) and configured with UPStart configuration software. Local response time is the time from rocker press to load response. Similarly, blink rate levels can be adjusted.

POWER DISCONNECTION

To disconnect power to the connected lamp fixture, depress the top of the rocker switch, grab the underside of the clear plastic indicator tab with your fingernail, pull the tab out about 0.2" until it stays in place. The LED indicator will extinguish to show that power is now disconnected. To reconnect power, simply push the tab back into its normal position. Utilize this disconnect to prevent damage if wiring hot.

OVERLOAD PROTECTION


The US1-40 contains a thermal sensor that automatically turns off the connected load if the switch becomes too hot. This can occur when the load exceeds the power rating of the switch, or when dimming incompatible loads or if the switch is in an environment that exceeds the maximum operating temperature (120° F). If the load begins to turn OFF and ON repeatedly without command or actuation, then the load must be reduced.

UPB FACTORY DEFAULT SETTINGS

To restore the following default settings, place the US1 in SETUP mode and tap any actuator exactly 10 times. The indicator will continuously blink BLUE. Tap the actuator twice again to exit SETUP mode.

- Network Name "Network 1"
- Room Name "New Room Name"
- Device Name "New US1-40"
- Unit ID 34
- Network ID 255
- Network Password 1234
- Transmit Links None are pre-programmed
- Receive Links 1 (100%) and 2 (0%),

STANDARD 2-WAY INSTALLATION



INSTALLING/CHANGING FACEPLATES

The US1-40 SimplyBrilliant Dimming Wall Switch is designed with a removable actuator faceplate, making it possible to change color in the field without disconnecting the switch from the wall.

To install a faceplate assembly, do the following:

1. Hold the rocker faceplate assembly so that clear plastic light pipe (LED) on the switch fits nicely into the recess on the top of the rocker.
2. Align the four prongs on the rocker assembly with the four slots on the switch body.
3. With equal pressure on the top and bottom of the faceplate, squeeze prongs as you press it into the switch body. Ensure that all four prongs are fully inserted and latched into the switch body. If all four prongs are not fully latched, the rocker/button plungers may not function properly.
4. Exercise each rocker/button several times to ensure proper seating and operation. If the rocker or button doesn't operate properly, remove and re-install the faceplate to check proper seating and operation.

To remove the faceplate assembly to change color, do the following:


1. Remove the wall plate from the switch.
2. Using the thumb and index finger, press the top two prongs of the rocker faceplate assembly inward so that they unlatch from the switch body. This will release the top of the rocker assembly.
3. Press the two lower prongs inward, and pull the faceplate assembly away and slightly downward from the switch body, moving it away from the clear plastic light pipe.
4. Once the old rocker faceplate is removed, follow steps 1-4 above for instructions on installing a new rocker faceplate assembly.

STANDARD 3-WAY (OR MULTI-WAY) INSTALLATION

This diagram shows a 3-way wiring configuration in which a USR remote switch controls the load connected to a US1. Additional USR remote switches may be added in parallel for multi-way control.

STANDARD 3-WAY (OR MULTI-WAY) INSTALLATION

DO NOT CONNECT MECHANICAL/CONVENTIONAL 3-WAY SWITCH IN PLACE OF USR! DAMAGE WILL RESULT



TROUBLESHOOTING

PROBLEM	PROBABLE CAUSE	SOLUTION
Master switch is wired properly but has no power. (LED indicator is OFF)	Air gap power disconnect may be disengaged (pulled out).	Push light pipe (indicator) back into position flush with faceplate assembly housing.
Master switch actuator doesn't turn load ON and/or OFF. (LED indicator is ON)	Actuator faceplate may not be seated properly on the switch body.	Exercise actuator several times to ensure proper seating and operation. If necessary, remove and replace faceplate to ensure proper seating and operation.
	3-way remote switch actuator may be binding, causing the switch to be stuck ON or OFF.	Loosen mounting screws on remote switch and/or wallplate to relieve pressure on housing.
Buttons and/or rockers stick or don't actuate properly when pressed.	Mounting screws may be too tight or j-box may be deformed, causing the switch body to warp.	Loosen mounting screws to relieve pressure on the switch housing.
	Actuator springs may have backed out of their correct location during shipping.	Exercise actuator several times to ensure proper seating and operation. If necessary, remove and replace faceplate to ensure proper seating and operation.
Load turns ON and OFF regularly without actuation or command.	Switch is overloaded.	Reduce the power load by removing bulbs from the circuit.
	Switch is dimming a load that is not rated for use with incandescent dimmers.	Reconfigure the switch for ON/OFF operation with no dimming (using UPStart, for example).
Multi-button/rocker faceplate is not recognized in UPStart and does not work	US1-40 is configured for a single rocker ONLY. Multi-button/rocker faceplates will not be recognized by UPStart	Replace US1-40 with a US2-40 and the desired faceplate (timer option not available in US2-40).

