



If the computer interface module is connected to phase B then the ZPCI that is located in the “new Box” would be wired from panel 1 phase B to panel 2 phase A.

This is another way to do it. I'm not sure which scenario will work the best at your location.

